Battery Maintenance and Troubleshooting Guide



Proprietary Notice

This manual, including the design and principles of construction disclosed within it, is the property of Jervis B. Webb Company. It is submitted with the understanding that it is not to be reproduced, nor copied in whole or in part, nor loaned or otherwise communicated to any third party, nor used in any manner detrimental to the interests of the Jervis B. Webb Company without its expressed consent.

The following are registered trademarks or trademarks of the Jervis B. Webb Company (JBW): SMARTCART, SAM^{TM} , CARTTOOLS, $SMARTVIEW^{TM}$, and $SMARTSERVER^{TM}$.

Jervis B. Webb Company 34375 West 12 Mile Road Farmington Hills, MI 48331-5264

Contact Customer Service at: 1-877-JB-Webb-1 (1-877-529-3221) webbservice@jerviswebb.com

Document Revisions

Date	Rev.#	Reviser	Description	
09-27-13	0.0	JEC	Initial release	
10-21-13	1.0	JAW	Major revision of content and format	

Document file name is: Battery Maintenance and Troubleshooting Guide Ver 1.0.docx Date last saved: 10/29/2013

Table of Contents i

TABLE OF CONTENTS

1	INTRODUCTION	1
2	BATTERY MAINTENANCE	1
2.1	Daily	
2.1	1.1 Auto Charge Systems	
2.1	1.2 Manual Charge Systems	2
2.2	Weekly Finish Charge	2
2.3	Monthly Finish Charge	2
2.4	Quarterly	2
2.5	Semi-Annual (Optional Suggested Testing)	2
3	BATTERY MAINTENANCE CHARGE	3
4	BATTERY RECOVERY CHARGE	4
5	BATTERY TROUBLESHOOTING	5
5.1	Battery Low Level Lockout (Battery Level 0)	5
5.2	Battery Charger will not Charge Battery	
6	EQUIPMENT FOR BATTERY TESTING AND MAINTENANCI	E 5



ii Table of Contents

This Page Intentionally Left Blank



1 Introduction

The life of the battery depends on the application and the maintenance schedule. To optimize battery life, proper maintenance and charging is required. It is also necessary to maintain records of battery maintenance, as these records are helpful in determining the condition of the battery (whether it is near the end of its life and needs to be replaced).

WARNING:

FAILURE TO USE THE BATTERY CHARGER SPECIFIED BY DAIFUKU WEBB FOR THE BATTERY TYPE AND APPLICATION WILL VOID THE BATTERY WARRANTY.

LACK OF PROPER BATTERY MAINTENANCE WILL ALSO VOID THE BATTERY WARRANTY.

2 Battery Maintenance

To optimize battery life, the following daily, weekly, monthly, quarterly and semi-annual battery maintenance schedule should be followed.

2.1 Daily

Daily maintenance requirements are different for manual and automatic charging systems. The following subsections will explain the specific requirements for each type of system.

<u>CAUTION</u>: Be careful not to over discharge the battery, as this will result in shortening the life of the battery. Follow battery charging guidelines to ensure batteries are not over discharged.

2.1.1 Auto Charge Systems

An auto charge system is designed to achieve maximum battery life by charging the batteries after each transport cycle or series of transport cycles. If a system is operated as designed, no daily maintenance is required.

Over discharge of the battery can occur if:

- The SmartCart is manually released and not given a full charge cycle as designed.
- A SmartCart remains powered up in a system that is not running at designed capacity for an extended period of time.

To recover from either of the above mentioned situations, check the battery for low life, and then charge the battery every night.



2.1.2 Manual Charge Systems

Batteries on a manual charge system should be charged at the end of the day, the shift, or when the battery is determined to be low (battery level 1). The battery should never be discharged to low level lockout (battery level 0). Allowing the battery to go to battery low level lockout will result in shorter battery life or damaged batteries.

2.2 Weekly Finish Charge

Batteries that are not charged for 6-8 hours on a manual charger or allowed to discharge to low level must be given a finish charge every week. A finish charge brings the level of charge on the battery to the maximum level, thereby providing optimum battery life.

To achieve a finish charge, charge the batteries for 6-10 hours on a manual charger. Refer to the Battery Maintenance Charge section for details.

Note: On an automatic battery charge system where the batteries are charged after 1-3 transport cycles, or series of transport cycles, the weekly finish charge frequency may be extended to monthly.

2.3 Monthly Finish Charge

On automatic charge system where the batteries are charged after 1-3 transport cycles, a monthly finish charge is recommended

2.4 Quarterly

Perform a manual charge on the batteries, and then measure and record the following voltage readings:

- Voltage of the battery pack as indicated on the HMI.
- Voltage of each battery as indicated by using a Multimeter.

If there is a significant change of one (1) volt from the readings of the previous month, or a difference of 0.5 volt in the reading between individual batteries it will be necessary to perform a recovery charge of the batteries. Refer to the Battery Recovery Charge section for details.

2.5 Semi-Annual (Optional Suggested Testing)

Perform the battery discharge test twice a year to determine the remaining life and condition of the battery. This is an optional test to prevent possible failure of the battery or low battery lockout during critical production periods.

Note: Perform a full battery maintenance charge prior to the battery discharge test, and after the discharge test is completed.

The discharge test must be performed on each battery individually.



To perform a battery discharge test, proceed as follows:

1. Perform a full maintenance charge of the batteries. Refer to the Battery Maintenance Charge section for details.

Note: The results of the maintenance charge may require a recovery charge.

- 2. Disconnect the batteries, and then remove them from the SmartCart.
- 3. Set the discharge time according to the chart shown below for the specific setting for the type of battery being tested.
- 4. Set the discharge shutoff voltage to 1.75 VPC.
- 5. Set the discharge rate to 25 amps.
- 6. Wait for the battery discharge test to be completed.
- 7. Record the minimum voltage, actual voltage, and cycle time in the battery maintenance log.
- 8. Check the results below to determine what needs to be done:
 - If the cycle time is equal to or less than the minimum cycle time listed in chart below, the battery is near the end of its life. The battery may continue to function and charge, but the charge rate and capacity will be reduced. This will result in reduced SmartCart run time per charge, and the SmartCart will require more frequent charge cycles.
 - If any of the batteries in the battery pack are at or near the end of their life, all the batteries in the pack should be replaced with new batteries.

Battery	Discharge Time Setting (minutes)	Minimum Cycle Time (minutes)
Enersys TPPL 36 AH	75	34
Enersys TPPL 89 AH	210	94
Deka AGV 105 AH	210	94

3 Battery Maintenance Charge

A maintenance charge will bring a battery pack to full charge, and to a complete charge with a finish charge cycle. A typical maintenance charge cycle with a finish charge will take 6-10 hours; the duration will vary based on the battery's initial state of charge.

To perform a battery maintenance charge, proceed as follows:

- 1. Allow the SmartCart to sit idle for 2 minutes.
- 2. On the HMI, check the battery pack voltage.
 - If the voltage is greater than 23 volts, place the SmartCart on a manual charger, which will provide a finish charge of the battery. This charge may take up to 10 hours.



- If the voltage is less than 23 volts, perform a battery recovery charge of each battery. Refer to the Battery Recovery Charge section for details.
- 3. Select the appropriate charger for your SmartCart/battery listed in the Equipment List section.
- 4. Plug the charger into the manual charge connection on the SmartCart.
- 5. Charge the battery until the charger indicates the charge is complete. Refer to the charger manual for details on charge features.

Note: If the charger does not turn on, the batteries will need a recovery charge, or will need to be replaced.

4 Battery Recovery Charge

A recovery charge must be performed if the batteries have been over discharged or sulfated. The individual battery must be charged independently with a special battery recovery charger.

Any individual 12V battery with a measured voltage of less than 11.5 volts is over discharged and may be sulfated. If it is determined that one of the batteries in a SmartCart battery pack needs a recovery charge, all the batteries in the pack should receive a battery recovery charge.

Note: Refer to the charger manual for additional details and cautions for charging the batteries.

To perform a battery recovery charge, proceed as follows:

- 1. Remove all connections from the battery.
- 2. Set the charger mode to 14.7V/3.3A.
- 3. Connect the charger to the battery following the instructions in the charger manual.
- 4. Leave the battery on the charger until the Charge Complete green light turns ON.

Note: If the battery does not reach 12 volts in 26 hours, replace the battery.

If the battery temperature reaches 113°F, stop the charge and replace the battery. (Temperature tabs are available to monitor temperature).

- 5. Reconnect the batteries in the SmartCart.
- 6. Perform a maintenance charge on the battery pack. Refer to the Battery Maintenance Charge section.



5 Battery Troubleshooting

5.1 Battery Low Level Lockout (Battery Level 0)

Battery lockout is a condition where the SmartCart has determined that the battery voltage has dropped to the low level limit. Operation of the SmartCart under these conditions will result in reduced battery life, damage to the battery, and poor automatic operation of the vehicle. The battery must be charged.

Note: The SmartCart can be moved to the battery maintenance charge area using a manual pendant.

To recover following a low battery lockout, proceed as follows:

- 1. Allow the SmartCart to sit idle for 2 minutes.
- 2. On the HMI, check the battery pack voltage.
 - If the voltage is greater than 23 volts, place the SmartCart on a manual charger, which will provide a finish charge of the battery. This charge may take up to 10 hours. Refer to the Battery Maintenance Charge section for details.
 - If the voltage is less than 23 volts, perform a battery recovery charge of each battery. Refer to the Battery Recovery Charge section for details.

5.2 Battery Charger will not Charge Battery

Batteries may become over discharged or sulfated as the batteries become older. In a manual charge system the frequency of required battery charges will increase as the batteries age, which may result in over discharged or sulfated batteries. If the manual or automatic charger will not turn on, or comes on and quickly turns off, a recovery charge is needed. Refer to the Battery Recovery Charge section for details.

6 Equipment for Battery Testing and Maintenance

Battery Type	Maintenance / Finish Charger	Recovery Charger for Single 12v Battery	Battery Tester for Single 12v Battery
Enersys TPPL 36 AH	Wahh #C1112210	Webb #C1113732	Webb #C1113731
Enersys TPPL 89 AH	Webb #C1113218		
Deka AGV 105 AH	Webb #C1097215		



This Page Intentionally Left Blank

